

PREVENTIVE MAINTENANCE SCHEDULE ON VEHICLES.

SERVICE 'A' @ 5,000KM

Carry out the following checks, repair or replacement:

- **Replace engine oil and sump oil drain plug gasket.**
- **Change oil filter.**
- **Replace pre filter if fitted/main fuel filter.**
- **Inspect air filter element, blow, replace if required.**
- **Check drive shaft rubber boot and their fittings.**
- **Check engine, gear box and transfer gear box mountings.**
- **Check exhaust line and mountings.**
- **Grease propeller shaft, spider kit, wheel hubs and tie rods.**
- **Check shock absorbers and their bushes.**
- **Check doors, play in hinges, presence of bushes.**
- **Clean vent on front and rear axles.**
- **Check hand brake, brake connections, hoses and fluid tank.**
- **Check bolts and mountings on lower arm suspension and spring leaves.**
- **Check free play on the steering and tie rods.**
- **Consult maintenance record book and rectify any problem stated.**
- **Complete visual check and repair or replace if necessary.**

**Next service 'B' is the addition of 5,000km to the present reading at service 'A'
= 10,000KM.**

PREVENTIVE MAINTENANCE SCHEDULE ON VEHICLES.

SERVICE 'B' CARRIED OUT AT 10,000KM or last service km reading + 5000km.

Carry out the following checks, repairs or replacements.

- **Replace engine oil and oil sump drain tap gasket.**
- **Change oil filter.**
- **Replace pre fuel filter if fitted**
- **Change diesel filter.**
- **Inspect air filter element, blow, replaced if required.**
- **Check drive shaft rubber boot and their fittings.**
- **Check engine, gear box, and transfer box mountings.**
- **Check exhaust line mountings.**
- **Grease propeller shaft, spider kit, wheel hubs and tie rods.**
- **Check shock absorbers and their bushes.**
- **Check doors, play in hinges, presence of bushes.**
- **Clean vent on front and rear axle.**
- **Check hand brake connections, hoses, and fluid tank.**
- **Check bolts and mountings on lower arm suspension and spring leaves.**
- **Check free play on the steering and tie rods.**
- **Consult maintenance record book and rectify any problem stated.**
- **Complete visual check and repair or replace if necessary.**
- **Dismantle and check control mechanism, brake shoes and pads, disc and drums. Check condition and thickness.**
- **Check gear box, transfer gear box, front and rear axle oil level.**
- **Rotate tires if necessary.**
- **Check body mounting and bolting.**

Next Service 'A' is the addition of 5,000km to the present reading of service at 'B' = 15,000KM. OR Last service KM reading + 5,000km.

PREVENTIVE MAINTENANCE SCHEDULE ON VEHICLES

SERVICE 'C' @ 40,000KM or after doing 5,000km service for 8 times i.e A, B, A, B, A, B, A then C. Last km reading +5,000km.

Carry out the following checks, repair or replacement:

- **Replace engine oil and sump oil drain tap gasket.**
- **Change oil filter.**
- **Replace pre fuel filter if fitted.**
- **Change diesel filter.**
- **Inspect air filter element, blow, replace if required.**
- **Check drive shaft rubber boot and their fittings.**
- **Check engine, gear box and transfer gear box mounting.**
- **Check exhaust line and mountings.**
- **Grease propeller shaft, spider kit, wheel hubs and tie rods.**
- **Check shock absorbers and their bushes.**
- **Check doors, play in hinges, presence of bushes.**
- **Clean vent on front and rear axle.**
- **Check hand brake, brake connections, hoses and fluid tank.**
- **Check bolts and mountings on lower arm suspension and spring leaves.**
- **Check free play at the steering and tie rods.**
- **Consult maintenance record book and rectify any problem stated.**
- **Complete visual check and repair or replace if necessary.**
- **Dismantle front and rear brakes, and cleaning of control mechanism, brake shoes and pads, discs and drums. Record thickness and change if necessary.**
- **Rotate or interchange tires if necessary.**
- **Check body mountings and bolting.**
- **Change gear box oil, transfer gear box oil, front and rear axle oil(GL5).**
- **Overhaul front and rear axle hubs.**
- **Replace radiator coolant.**

Next service 'A' is the addition of 5,000km to the present reading at service 'A' = 40,000KM.